


Griphoist-Tirfor

TU-17/TU-8 & TU-28/TU-16



Date: 04/05/04

Version:2a

Service and Maintenance Manual

Table of Contents

UL Listing Card	P. 3
Tools required	P. 4
General Inspection	P. 4
Disassemble TU-17/TU-8	P. 5
Disassemble the two jaw blocks	P. 8
Reassemble	P. 10
Front Jaw Assembly	P. 12
TU-17/TU-8 & TU-28/TU-16 Physical Differences	P. 19
TU-17/TU-8 Dimensions	P. 20
TU-28/TU-16 Dimensions	P. 21
Hydraulic Powered Units	P. 22
TU-28H vs. TU-28 Comparison	P. 23
Appendix A (exploded view for TU-17/TU-8 & TU-28/TU-16)	P. 24
Appendix B (Jaw Inspection)	P. 28



Griphoist Division

UL Listing Card



Northbrook, Illinois (847) 272- 8800
Melville, New York (631) 271-6200
Santa Clara, California (408) 985-2400
Research Triangle Park,
North Carolina (919) 549-1400
Camas, Washington (360) 817-5500

TRACTEL INC
GRIPHOIST DIV
110 SHAWMUT RD
PO BOX 188
CANTON, MA 02021

TUFV
Equipment, Scaffolding

April 18, 2002

TRACTEL INC GRIPHOIST DIV
110 SHAWMUT RD PO BOX 188, CANTON MA 02021

SA4785

Electric scaffold hoists, Models ETH-32L, XE301P, maximum load 700 lbs; Models ETH35C, ETH35C3, ETH35X, LE500P, **LE501P**, TE401P, -401PA, XE500P, -501P, -501PA, **maximum load 1000lbs**; Models TE1000P, -1001P, -1001PA, XE501PO, XE700P, -701P, XE720P, XE721P, maximum load 1500lbs; Models TE1020P, -1021P, -1021PA, maximum load 2000 lbs; Model XE1020P, maximum load 2400 lbs; Model XE2050P, maximum load 4400 lbs.

Manually operated scaffold hoists, Model TMS-600, maximum load 1320 lbs; Model TU-17, maximum load 1500 lbs; Model TU-28, maximum load 3000 lbs; Model TU-32, maximum load 6000 lbs; Model 408, maximum load 880 lbs.

Pneumatic scaffold hoists, Models ATH32L, -32LB, XA300P, -300PB, maximum load 700 lbs; Models ATH35C ATH35X, -35XB, LA500P, XA500P, -500PB, maximum load 1000 lbs; Models XA700P, -700PB, XA720PB, maximum load 1500 lbs; Model XA1030PO, maximum load 1850 lbs; Model TA1020P, maximum load 2000 lbs; Model XA1020P, maximum load 2400 lbs; Model XA2050P, maximum load 4400 lbs; Model XA2650P, maximum load 5300 lbs.

Independent secondary brakes, Model BS15.301, maximum load 1500 lbs; Model BS20.301, maximum load 3000 lbs; Model BS35.301, maximum load 6000 lbs.

Modular work platform, "Modular Staging", 2 to 12 m, rated 750 lbs; Models KD01, MP03, 2 to 18m, rated 750 to 1500 lbs; "PFD", 2 to 15m, load 6000 lbs.

Work Cages, Model PMR0700D, PMR0701D, VSMV-PMR0710D, rated 1000 lbs; Model WC01, rated 400 lbs.

This equipment consists of separate parts inspected at the factory by Underwriters Laboratories Inc. and is intended for use in complete complete installations. Installations are not inspected by Underwriters Laboratories Inc. but should be made in accordance with requirements of authorities having jurisdiction.

LOOK FOR CLASSIFICATION MARK ON PRODUCT



Tools required



Hammer
Screwdriver (Flat head)
Gear puller
Pliers
Wrenches
-10mm (TU-17 / TU-8)
-13mm (TU-28 / TU-16)
2 nails (for jaw spring compression)
General purpose grease

General Inspection



Check for casing deformation or damage as shown above. Severe deformity needs casing replacement. Small dents can be hammered flat on an anvil.

Disassemble TU-17 / TU-8



Use a gear puller to remove power stroke lever and shear pins.



Remove the handle and aluminum shear pins. (2 shear pins for TU-17, 3 shear pins from TU-28) If shear pins are broken, hoist has been overloaded. If shear pins have been replaced by steel fasteners, screws or welded the crankshaft / power stroke lever assembly must be replaced.



Place Tirtor on vice for easier removal of casing screws.



2 sets of spare shear pins are found in the power stroke lever under a plastic cap. If missing replace them.

Check that mushroom capped rivet is in place. It holds the telescopic handle in place.



Griphoist Division



Remove casing screws.
10mm wrench TU-17 / TU-8



Check for wear or any loose parts (snap rings) inside casing cover.

Check that both casing bushings are in place and in good condition. No splits, etc.



Remove casing cover once casing screws are removed.



Check for bent safety latch on hook. Repair or replace as necessary. check latching function. Make sure that the hook is not opened due to a tip load.



Check for roller damage. If axle has punched out hole in center of roller replace it.



Use pliers to adjust bent safety latch. Side plates should be parallel.



Broken roller (TU-17/TU-8) as shown above need to be replaced.



Check that clutch pusher has not been mushroomed by hammering. This shows that user tried to move it with anchor hook extended.

Disassemble the two jaw blocks



Remove pin snap ring (5 mm) from upper pin of reversing lever (Position. 040) and clutch pin (Position. 041)



Push pins through reversing lever and disassemble reversing lever connecting rod



Remove pin snap from reversing lever pin (Position. 39) and remove reversing lever connecting rod from assembly.



Remove pin snap from crankshaft connecting rod (Position. 919) and remove crankshaft power stroke lever. Check that nylon bushings are in place and not broken.



Griphoist Division



Warning: Never remove jaw pins until springs has been compressed and nail is placed through hole in shaft to prevent it from flying upon disassembly.



Compress the springs and place a nail in jaw spring shaft before removing spring from jaw assembly.



Inspect jaw wear and replace when nessasary. (see appendix B for jaw inspection)



Dissassemble front jaw the same way.

Thoroughly clean and inspect all parts before reassemble. New grease must be applied for reassembly.



Warning! Do not use any grease with graphite or molydisulphide. These can cause slippage between the wire rope and jaws.



Remove pin snap ring from pin (Position. 032 & Position. 034) and disassemble jaw assembly



Griphoist Division

Reassemble




Assemble jaw as shown above. (Refer to exploded view in appendix A for assembly)

Generously grease each part and start assembly by laying down jaw actuating cam and free cam (Position. 14 & Position. 15)


Note: Make sure to apply extreme pressure grease to the jaw keys. Lack of lubrication on the S shaped jaw keys can cause the jaws to stick and "pumping occurs where the rope does not advance through the machine when operating.



Griphoist Division



Slide rear jaw connecting plate over the jaw assembly. Be careful that the S shaped jaw keys do not fall out.



Place spring in position, apply pressure to aw cam to compress the spring slightly and remove the nail. Finalize assembly by placing pin snap back on pin and center the axle for the rollers.



Place 4 flat washers and 1 spacer in to assembly for complete rear jaw assembly. (Refer to appendix A for exploded assembly view)




Griphoist Division

Front jaw assembly



Grease nylon roller and place roller with washers on to jaw assembly pin. (Position. 034)



Place crankshaft on to rear jaw connecting plates. Make sure that the stop pin is recessed in the side plate slot.



Generously grease each part and assemble jaw the same way as rear jaw.



Griphoist Division



Place bushing between free cams. Place jaw assembly into front jaw assembly plate. Place 4 flat washer and pin in alignment.

Once assembly finalized, remove nail and secure pin in assembly by pin snap ring.



Grease roller and place roller on jaw assembly pin on guide roller. (Position. 034)



Secure crankshaft connecting pin with pin snap ring.



Connect front and rear jaw with crankshaft. (Position. 919)



Start reversing lever assembly by fasten lever in place with reversing lever pin (Position. 039)



Place spacer and fasten reversing lever connecting rods with reversing lever pin.
(Position. 039)




Assemble clutch actuating lever sub assembly to reversing lever. Secure assembly with pin and pin snap ring.





Assemble reversing connecting rods
(Position.021) to Reversing lever (Position.
903)



Griphoist Division




Grease right hand casing and check for casing deformity, nylon bushing, and bearing wear.




Make sure casing spacer thread (Position. 045) is fastened before placing the jaws into cover.


Place jaws into casing and tuck the spring on clutch actuating lever in to casing. Use a vise grip to hold clutch actuating lever in place.



Assemble clutch lock pusher into casing.




Place left hand casing over assembly.



Place rope entry in position.



Start tightening all casing screws.



Place anchoring hook in position.



Place hoist on vise for easier assembly.



Fasten through casing screw.



Make sure casing flange is in place for fastening



Grease shaft and install power stroke lever on crankshaft. Secure it with 2 new shear pins for TU-17/TU-8 and 3 for TU-28/TU-18. Do not reuse shear pins.


TU-17 / TU-8 & TU-28/TU-16 Physical Differences

TU-28 appears to look like the TU-17 with the exception in size and several minor differences which are described below.

The Hook



TU-28 shown above has a loose casing strengthener to reinforce the area around the hook.



TU-17 shown above does not have a loose casing strengthener, but has reinforcement in the hook area of the casing.



TU-28 has a carrying handle.



TU-17 does not have carrying handle.



TU-28's crankshaft w/ power stroke lever has 3 aluminum shear pins.



TU-17's crankshaft w/ power stroke lever has 2 aluminum shear pins.

The clutch lock pusher with spring




TU-28's clutch lock pusher with.




TU-17's clutch lock pusher with spring.

TU-17 Dimensions

- ① Shear pins
- ② Rope guide
- ③ Spare shear pins



Telescopic Control Lever




Rated Load lbs. (kg)	Wire Rope in. (mm)	Effort to control lever lbs. (kg)		Rope Travel in. (mm)		Dimensions in.													Weight lbs. (kg)	
		forward	reverse	forward	reverse	A	B	C	D	E	F	G	H	I	J	K	L	M		N
2,000 (800)	5/16 (8.3)	79 (36)	40 (18)	2 (50)	2.4 (60)	10.6 (270)	1.3 (32)	1.2 (30)	1.6 (40)	20.9 (530)	15.6 (397)	2.8 (70)	76.6 (194.5)	2.3 (58)	1.1 (28)	11.2 (285)	4.3 (110)	17.9 (455)	28.9 (735)	19 (8.5)




GripHoist Division

TU-28 Dimensions

- ① Shear pins
- ② Rope guide
- ③ Spare shear pins



Telescope Control Lever




Rated Load lbs. (kg)	Wire Rope in. (mm)	Effort to control lever lbs. (kg)		Rope Travel in. (mm)		Dimensions in.													Weight lbs. (kg)	
		forward	reverse	forward	reverse	A	B	C	D	E	F	G	H	I	J	K	L	M		N
4,000 (1,600)	7/16 (11.5)	119 (54)	44 (20)	2.2 (56)	2.8 (70)	12.8 (325)	1.5 (38)	1.2 (30)	1.9 (48)	26 (660)	19 (483)	3.4 (85.5)	9.3 (238)	3.1 (80)	1.2 (31)	14.2 (360)	5.7 (145)	25.4 (645)	45.3 (1150)	41 (18.5)




GripHoist Division

Hydraulic Powered Units



The hydraulic powered Tirfors are special machines that is powered by a self reciprocating hydraulic cylinder. Since fatigue of the operator is not a factor, these machines are typically used for heavy loads over a longer distance. For extra durability and more severe service, the hydraulic machines have bearings in place of bushings and heat treated components.



GripHOIST Division

TU-28H vs. TU-28 Comparison

TU-28H is a hydraulic powered device. It differs from a regular TU-28 in the components used. Below are illustrations of the differences.



Power stroke lever shown above clearly demonstrates the difference between a hydraulic unit which is on the left and a standard unit on the right.

Note: Shear pins for hydrolic units are steel compare to aluminum for regular hand operated unit.



Crankshaft for hydraulic units has needle bearings demonstrated above on the left vs. standard hand operated unit which does not have bearing shown on above right.



Both front and rear jaws for hydraulic unit has red paint indicating extra hardening shown on above left.



Top crankshaft TU-28H has reinforced needle bearing contact surface vs. lower crankshaft that has no reinforced contact surface with casing.



Hydrolic unit has tapered hook base shown on left vs. ridgid base on a regular hand operated unit shown on right.







Left picture shows reinforced TU-28H casing with needle bearing vs. right picture that has nylon bushing for standard hand operated unit.

TIRFOR TU-17				Assemblies complete			
Code				Code			
N°	SSA	TSA	Designation	N°	SSA	TSA	Designation
005	10445	0082.002.01	clutch actuating lever	(901)	(4227)	0082.922	crankshaft with power stroke lever
009	10455	0080.007	jaw actuating key	903	4197	0082.914.01	reversing lever
(011)	(10475)	(0082.000)	lower jaw	904	9577	0084.900	anchoring hook with safety catch (925)
014	10505	0082.005	jaw actuating cam	(905)	(4247)	(0082.905)	right hand casing with bearing and bushing
015	10515	0080.008	free cam	(906)	(4257)	(0082.906)	left hand casing with bearing and bushing
016	10525	0082.028	jaw pin distance plate	910	5307	0082.924	set bolts and nuts for casing compr.
018	9816	0433.445	jaw pin washer D 13x19x1 EP1 DIN 988				1 spacer (045), 2 screws (070), 2 screws (071)
021	10575	0082.006	reversing lever connecting rod				2 screws (075), 1 screw (089), 1 nut (088)
022	10585	0082.007	clutch actuating cam	911	5317	0082.925	and 8 nuts (072)
028	21295	0084.001	clutch lock pusher				casing complete, compr. RH casing (905), LH casing (906) and bolts/nuts (910)
032	22715	0080.102	rear jaw assembly pin	912	6347	0082.926	crankshaft (901) power stroke lever with
034	10845	0080.053	jaw assembly pin on guide rollers	(913)	(4287)	(0082.909)	6 safety shear pins (053) and 1 cap (054)
035	10855	0082.027	front jaw assembly pin	914	5317	0082.927	upper jaw complete
037	10875	0080.024	jaw assembly bushing				jaw assembly compr. 2 upper (813) and
039	20045	0080.027	reversing lever pin				2 lower jaws (011)
040	10795	0082.012	upper pin of reversing lever	915	5337	0082.910	front jaw connecting plates compr.
041	10715	0080.041	clutch pin	916	5337	0082.911	rear jaw connecting plates compr.
042	10725	0082.013.01	clutch actuating lever pin	917	5347	0080.904	jaw spring complete
043	10735	0082.014	long shoulder rivet	919	5387	0080.014	crankshaft connecting rod pin
044	10745	0082.015	short shoulder rivet	920	4577	-	set of 30 shear pins (053)
(045)	(10755)	(0080.064.01)	casing spacer, threaded	921	9807	-	set of 10 plastic caps (054)
048	585	0070.104.01	rope entry	925	11417	0082.928	safety catch complete for hook (904)
052	19426	0433.443	washer D 13x25 EP3 DIN 1441	995	1207	9830.999	wire rope hook with "T" safety catch (996)
(053)	(9838)	(0434.616)	safety shear pin 6x14.5	996	5257	9082.855	"T" type safety catch for hook (995)
(054)	(19406)	(0519.310)	plastic cap for shear pin container	997	508	0070.924	telescopic operating handle complete
056	10765	0080.061	nylon bushing				
057	10795	0080.082	guide roller				
062	2946	0433.855	pin snap ring 9 DIN 6799				
063	6036	0433.851	pin snap ring 5 DIN 6799				
064	15516	0433.004	clutch pin washer A 8,4 DIN 125				
065	10825	0082.016	clutch lock pusher spring				
068	10835	0082.017	clutch spring				
067	20025	0085.017.01	casing flange				
(068)	(7996)	(0432.512)	NYLOC nut HM6				
(069)	(29306)	(0431.050.01)	screw TH M 6x70/18				
(070)	(166)	(0431.037.01)	short casing screw M 6x10 DIN 933				
(071)	(38)	(0431.040.01)	long casing screw M 6x20 DIN 931				
(072)	(266)	(0432.003.01)	casing nut H M 6 DIN 934				
073	-	-	instruction plate				
074	-	-	name plate				
(075)	(46)	(0431.041.01)	screw M 6x25/21				

* parts only supplied in full set per machine.

IMPORTANT

When ordering spare parts, please mention code n° of parts required as well as serial number of machine in need of repair.



TU-28 exploded view

GRIPHOIST TU-28 Assembly materials

No. Code	Description	No. per machine
(201) (9837)	upper jaw components	(2) U. Assy, 821
922 15427	front jaw connecting plate complete	1
923 9417	rear jaw connecting plate complete	1
924 9447	jaw spring components	2
925 9457	6x10 inch pulley	1
919 9557	crankshaft connecting rod pin	2
(118) (2127)	right hand crank with bearing and bushing	(1) L. Assy, 822
(119) (2737)	left hand crank with bearing and bushing	(1) L. Assy, 822
917 4117	reversing lever	1
920 4077	set of 30 safety shear pins (2000)	1
921 9607	set of 10 safety pins (2001)	1
922 5777	driveline hook with safety catch (2002)	(1) L. Assy, 823
(923) (9247)	crankshaft	(1) L. Assy, 823
(924) (257)	power stroke lever	(1) L. Assy, 929
929 11497	wire mesh complete for hook (2229)	1
921 9687	jaw assembly carrier, 2 upper jaws (911) and 2 lower jaws (204)	1
922 9397	crank connecting bearings, RH casting (218), LH casting (218) and ball bearings (204)	1
923 9417	crankshaft (2009) revolve lever complete, complete crankshaft (2009), power stroke lever (204) with 8 safety shear pins (2001) and 1 cap (2061)	1
924 9407	set of bolts and nuts for casting, complete, 3 screws (2009), 2 screws (2009), 1 screw (2009), 5 nuts (219) and 1 nut (218.1)	1
924 1167	wire rope hook with "g" safety catch (204)	1
924 2287	"g" type safety catch complete for hook (2009)	1
924 18	3x4 diameter operating handle	1

GRIPHOIST TU-28





No. Code	Description	No. per machine
(204) (2032)	lower jaw	(2) U. Assy, 821
002 8246	jaw actuating arm	4*
007 8226	jaw actuating bar	4*
008 8228	rod arm	4*
012 22045	jaw assembly pin on guide rollers	2*
014 22055	jaw assembly pin	2
015 4042	drutch pin weather	4*
(119) (273)	casting nut H 140 DIN 934	(2) L. Assy, 824
(119-1) (2898)	casting nut Aylco H 140	(2) L. Assy, 824
023 8485	reversing lever connecting rod	2
024 8528	jaw pin weather 1/2"x2 1/4" J 6 DIN pin	4*
025 8515	jaw assembly bushing - front block	1*
029 4749	pin strap ring 1/2" DIN 9799	10*
024 8546	drutch pin	2
025 8525	reversing lever of jaw pin	1
026 8526	drutch actuating arm	2*
027 8527	instruction plate	1
028 8528	hardware plate	1
040 9675	reversing lever pin - rear block	1
041 9649	pin strap ring 9/16" DIN 9799	8*
042 8525	reversing lower pin - front block	1
044 9695	reversing lower pin bushing	3
047 22725	guide roller	4*
051 1185	rope entry	1
(205) (8718)	casting spacer threaded	(1) L. Assy, 824
054 1823	bearing ring	2*
(206) (9638)	drutch pin 8x1 1/2	2*
(207) (1791)	casting screw TH 140 DIN 934	(2) L. Assy, 824
(208-1) (2002)	casting screw TH 140 DIN 934	(2) L. Assy, 824
(208) (2002)	casting screw TH 140 DIN 934	(1) L. Assy, 824
029 8232	carrying handle	1
(209) (4588)	arm TH 140 DIN 934	(2) L. Assy, 824
030 8246	drutch lock pulmer screw	1
(210) (18402)	cap for drive pin weather	(1) L. Assy, 821
036 18798	pin bearing A-16 DIN 7928	2
037 8536	drutch actring pin	1
038 8545	drutch actring lever	1
039 8555	drutch pin bushing	2*
073 8725	casting strengthening	1
074 8298	drutch spring	1
075 22895	casting flange	2*

*Parts only supplied in full sets per machine.

REMARKS:
When ordering spare parts, please mention code no. of parts required as well as serial number of machine in case of request.



GripHOIST Division



 **Tractel** Group


Griphoist Division

Appendix B

Jaw inspection

The Wear on the jaws of the tirfor hoists is generally very small. It is nevertheless recommended to check periodically the wear when inspecting and repairing the machines. This checking can be made on mounted jaws.

- 1) Introduce the measuring rod (see table for diameter according to model) between both jaws;
- 2) Place a square under jaw assembly pins:
 - a) if the hole of reversing lever pin is still partially covered by the square, the jaws are OK;
 - b) if this hole is completely uncovered, the jaws are worn and must be replaced. In this case, better check also the other wear parts mentioned in the list hereunder and eventually replace them at the same time.



List of jaws wear parts:

Pos.	Designation	Parts Qty per hoist	Code number for hoists:	
			TU-8/TU-8S/TU-10/TU-17	TU-16/TU-20/TU-28
1	Two sets of upper and lower jaw assemblies	1	5317	3387
2	Jaw actuating key	4	10455	8355
3	Free cam	4	10515	8365
4	Jaw actuating cam	4	10505	8345



GripHoist Division